



FireWire 800 2-Port ExpressCard/34 Quick Installation Guide

Introducing the *FireWire 800 ExpressCard*

The *FireWire 800 2-Port ExpressCard/34* adds FireWire 800 (1394b) interface to your ExpressCard equipped notebook computer.

Features and Benefits

- Provides 2 FireWire 800 (9-pin) ports for multiple device connections
- Supports data transfer rates up to 800Mb/s
- Supports hot-swap, hot-plug and Plug-n-Play connection of peripheral devices
- Works with DV camcorders, CD-RW/DVD-ROM drives, FireWire hard disks, digital cameras and other audio/video devices

System Requirements

- ExpressCard-enabled notebook computer with an available ExpressCard slot
- Windows® 2000/XP (32-/64-bit)/Server 2003 (32-/64-bit)/Vista (32-/64-bit)
- Mac OS X (10.4.x) or later

Package Contents

- *FireWire 800 2-Port ExpressCard/34*
- Driver CD
- Quick Installation Guide

Layout



Figure 1. Layout

***Note:** FireWire devices that have their own power supply do not require the optional power adapter to be connected in order to work. However, non-powered FireWire devices require this optional power adapter to work. The power adapter can be purchased at SIIG's Online Store, part# NN-ADA011.

Hardware Installation

General instructions for installing the card are provided below. Since the design of notebook computers may vary, refer to your system's reference manual for further information, if needed.

Insert the ExpressCard into the ExpressCard slot of your notebook computer. Make sure it is inserted all the way in for a solid connection.

Driver Installation

This section provides information on how to install the FireWire 800 drivers.

Windows 2000

Windows 2000 automatically installs its built-in 1394a driver for the *FireWire 800 2-Port ExpressCard/34*. To get the full speed out of this controller, install the FireWire 800 driver using the directions below.

1. Insert the driver CD. Click **Start, Run**. Type **D:\setup32.exe**, click **OK**. (Change **D:** to match the drive letter of your CD-ROM)
2. At the Welcome screen, click **Next**.
3. At the License Agreement screen, click **Yes**.
4. At the Destination Location screen, click **Next**.
5. Select **Complete**, then click **Next**.
6. At the Program Folder screen, click **Next**.
7. At the Digital Signature screen, click **Yes**, then click **Finish**.
8. Select the restart Windows option, then click **Finish**.

32-bit Windows XP

Windows XP automatically installs its built-in 1394a driver for the *FireWire 800 2-Port ExpressCard/34*. To get the full speed out of this controller, install the FireWire 800 driver using the directions below.

1. Insert the driver CD. Click **Start, Run**. Type **D:\setup32.exe**, click **OK**. (Change **D:** to match the drive letter of your CD-ROM)
2. At the Welcome screen, click **Next**.

3. At the License Agreement screen, click **Yes**.
4. At the Destination Location screen, click **Next**.
5. Select **Complete**, then click **Next**.
6. At the Program Folder screen, click **Next**.
7. At the Software Installation screen, click **Continue Anyway**, then click **Finish**.
8. Select the restart Windows option, then click **Finish**.

64-bit Windows XP

Windows XP automatically installs its built-in 1394a driver for the *FireWire 800 2-Port ExpressCard/34*. To get the full speed out of this controller, install the FireWire 800 driver using the directions below.

1. Insert the driver CD. Click **Start, Run**. Type **D:\setup64.exe**, click **OK**. (Change D: to match the drive letter of your CD-ROM)
2. At the Welcome screen, click **Next**.
3. At the License Agreement screen, click **Yes**.
4. At the Destination Location screen, click **Next**.
5. Select **Complete**, then click **Next**.
6. At the Program Folder screen, click **Next**.
7. At the Security Alert box, click **Yes** two times.
8. At the Software Installation screen, click **Continue Anyway**, then click **Finish**.
9. Select the restart Windows option, then click **Finish**.

32-bit Windows Server 2003

Windows Server 2003 automatically installs its built-in FireWire 400 driver for the *FireWire 800 2-Port ExpressCard/34*. To get the full speed out of this controller, install the FireWire 800 driver using the directions below.

1. Insert the driver CD. Click **Start, Run**. Type **D:\setup32.exe**, click **OK**. (Change **D:** to match the drive letter of your CD-ROM)
2. At the Welcome screen, click **Next**.
3. At the License Agreement screen, click **Yes**.
4. At the Destination Location screen, click **Next**.
5. Select **Complete**, then click **Next**.
6. At the Program Folder screen, click **Next**.
7. At the Security Alert box, click **Yes** two times.
8. At the Software Installation screen, click **Continue Anyway**, then click **Finish**.
9. Select the restart Windows option, then click **Finish**.

64-bit Windows Server 2003

Windows Server 2003 automatically installs its built-in FireWire 400 driver for the *FireWire 800 2-Port ExpressCard/34*. To get the full speed out of this controller, install the FireWire 800 driver using the directions below.

1. Insert the driver CD. Click **Start, Run**. Type **D:\setup64.exe**, click **OK**. (Change **D:** to match the drive letter of your CD-ROM)
2. At the Welcome screen, click **Next**.
3. At the License Agreement screen, click **Yes**.
4. At the Destination Location screen, click **Next**.
5. Select **Complete**, then click **Next**.
6. At the Program Folder screen, click **Next**.

7. At the Security Alert box, click **Yes** two times.
8. At the Software Installation screen, click **Continue Anyway**, then click **Finish**.
9. Select the restart Windows option, then click **Finish**.

32-bit Windows Vista™

Windows Vista operating system automatically installs its built-in FireWire 400 driver for the *FireWire 800 2-Port ExpressCard/34*. To get the full speed out of this controller, install the FireWire 800 driver using the directions below.

1. Insert the driver CD. Click **Start**, in the Start Search box, type **D:\setup32.exe**, press **Enter**. (Change **D:** to match the drive letter of your CD-ROM)
2. Click **Allow**.
3. At the Welcome screen, click **Next**.
4. At the License Agreement screen, click **Yes**.
5. At the Destination Location screen, click **Next**.
6. Select **Complete**, then click **Next**.
7. At the Program Folder screen, click **Next**.
8. At the Windows Security box, click **Install** three times, then click **Finish**.
9. Select the restart Windows option, then click **Finish**.

64-bit Windows Vista

Windows Vista automatically installs its built-in FireWire 400 driver for the *FireWire 800 2-Port ExpressCard/34*. To get the full speed out of this controller, install the FireWire 800 driver using the directions below.

1. Insert the driver CD. Click **Start**, in the Start Search box, type **D:\setup64.exe**, press **Enter**. (Change **D:** to match the drive letter of your CD-ROM)

2. Click **Allow**.
3. At the Welcome screen, click **Next**.
4. At the License Agreement screen, click **Yes**.
5. At the Destination Location screen, click **Next**.
6. Select **Complete**, then click **Next**.
7. At the Program Folder screen, click **Next**.
8. At the Windows Security box, click **Install** three times, then click **Finish**.
9. Select the restart Windows option, then click **Finish**.

Verify Windows Installation

1. Check Device Manager for proper installation.
For 2000/XP/Server 2003: Right click **My Computer**, click **Manage**, then click **Device Manager**.
For Window Vista: Right click **Computer**, click **Manage**, click **Continue**, click **Device Manager**.
2. Double click **1394 Bus host controllers**. **Unibrain driver/OHCI Compatible Board** should be displayed.

Mac OS X (10.4.x) or later

Mac OS will automatically detect and install the correct driver for the *FireWire 800 2-Port ExpressCard/34*. No additional driver is necessary.

To Verify Mac OS Installation

Check **System Profiler** to verify successful installation.

1. Click **Go**, then **Utilities**.
2. Double click **System Profiler**.
3. Click **FireWire** and another **FireWire Bus** should be displayed.

Connecting Devices

General driver installation steps are provided below. Please review your device's user manual for more details.

Windows 2000

1. At the Found New Hardware Wizard, click **Next**.
2. Select **Search for a suitable driver...**, then click **Next**.
3. Uncheck all check boxes, then click **Next**.
4. Click **Next**, then click **Finish** to complete the installation.

Windows XP

1. At the Found New Hardware Wizard.
For XP w/SP2 or later: Select **No, not this time**, then click **Next**.
For XP w/SP1 or earlier: Go directly to step #2.
2. Select **Install the Software Automatically**, click **Next**.
3. Click **Continue Anyway**. (Skip if not prompted)
4. Click **Finish** to complete the installation.

Windows Server 2003

1. At the Found New Hardware Wizard,
For 2003 w/SP1 or later: Select **No, not this time**, then click **Next**.
For 2003: Go directly to step #2.
2. Select **Install the Software Automatically**, click **Next**.
3. At the Security Alert box click **Yes**, or the Hardware Installation box click **Continue Anyway**, then click **Finish** to complete the installation.

Windows Vista

Windows Vista will automatically detect and install most FireWire devices when connected. However, for devices that do not install automatically, follow the steps below to complete the installation.

1. Click **Locate and install driver software**.
2. Click **Continue** to complete the installation.

Mac OS

Mac OS will automatically detect and install most FireWire devices when connected. If additional drivers are required, refer to the device's users manual.

Removing the ExpressCard

Stop the ExpressCard before removing it from the ExpressCard slot.

Windows

The utility is located by the system clock.

1. Click the **Unplug or Eject Hardware** or **Safely Remove Hardware** icon. Click **Remove PCI standard PCI-to-PCI bridge**.
2. Wait for the confirmation box, then remove the ExpressCard from the ExpressCard slot.

Mac OS

The utility is located by the system clock.

1. Click the **monitor** icon, then choose **Power Off Card**.
2. You can now remove the ExpressCard from the ExpressCard slot.

ubSwitch Utility (Windows only)

In order to use a DV camcorder with this controller, Microsoft's FireWire 400 driver must be installed in the system. We have supplied an easy to use utility that allows switching between Microsoft's driver and the FireWire 800 driver. *Before using this utility, unplug all devices from the FireWire 800 2-Port ExpressCard/34.*

1. Click **Start, Programs, Unibrain ubcore, Tools** then **ubSwitch**.
2. Right click the **ubSwitch** icon located in the system tray by the clock.
3. Click the **1394 Adapter** that you want to switch, then click on **Microsoft 1394 Drivers**.

Note: If your system has multiple 1394 adapters installed, make sure that you click on the 1394 adapter that the camcorder will be plugged into.

4. Windows will display an information box when the driver is ready for use. It may take a few seconds for this box to appear.

Note: To switch back to the FireWire 800 driver, follow the same procedures, but in step 3 instead of clicking on **Microsoft 1394 Drivers**, click on **Unibrain 1394 Drivers**.

Technical Support and Warranty

QUESTIONS? SIIG's **Online Support** has answers! Simply visit our web site at www.siig.com and click **Support**. Our online support database is updated daily with new drivers and solutions. Answers to your questions could be just a few clicks away. You can also submit questions online and a technical support analysts will promptly respond.

SIIG offers a lifetime manufacturer warranty with this product. Please see our web site for more warranty details. If you encounter any problems with this product, please follow the procedures below.

A) If it is within the store's return policy period, please return the product to the store where you purchased from.

B) If your purchase has passed the store's return policy period, please follow these steps to have the product repaired or replaced.

Step 1: Submit your RMA request.

Go to www.siig.com, click **Support**, then **RMA** to submit a request to [SIIG RMA](#). If the product is determined to be defective, an RMA number will be issued. SIIG RMA department can also be reached at (510) 413-5333.

Step 2: After obtaining an RMA number, ship the product.

- Properly pack the product for shipping. All software, cable(s) and any other accessories that came with the original package must be included.
- Clearly write your RMA number on the top of the returned package. SIIG will refuse to accept any shipping package, and will not be responsible for a product returned without an RMA number posted on the outside of the shipping carton.
- You are responsible for the cost of shipping. Ship the product to the following address:

SIIG, Inc.
6078 Stewart Avenue
Fremont, CA 94538-3152, USA
RMA #: _____

- SIIG will ship the repaired or replaced product via Ground in the U.S. and International Economy outside of the U.S. at no cost to the customer.

About SIIG, Inc.

Founded in 1985, SIIG, Inc. is a leading computer upgrade manufacturer of I/O connectivity products, including PCI & ISA serial and parallel ports, USB, Serial ATA & UltraATA controllers, FireWire (1394a/b), networking, sound cards, and other accessories. SIIG is the premier one-stop source of upgrades.

SIIG products offer comprehensive user manuals, many user-friendly features, and are backed by an extensive manufacturer warranty. High-quality control standards are evident by the overall ease of installation and compatibility of our products, as well as one of the lowest defective return rates in the industry. SIIG products can be found in computer retail stores, mail order catalogs, through major distributors, system integrators, and VARs in the Americas and the UK, and through e-commerce sites.

PRODUCT NAME

FireWire 800 2-Port ExpressCard/34

FCC RULES: TESTED TO COMPLY WITH FCC PART 15, CLASS
B OPERATING ENVIRONMENT: FOR HOME OR OFFICE USE

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

THE PARTY RESPONSIBLE FOR PRODUCT COMPLIANCE

SIIG, Inc.
6078 Stewart Avenue
Fremont, CA 94538-3152, USA

FireWire 800 2-Port ExpressCard/34 is a trademark of SIIG, Inc. SIIG and the SIIG logo are registered trademarks of SIIG, Inc. Microsoft, Windows and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Mac and MacOS are registered trademarks of Apple Computer, Inc. Other names used in this publication are for identification only and may be trademarks of their respective companies.